


TV STAND

USER MANUAL



SAVE THESE INSTRUCTIONS FOR FUTURE USE







Before Installation



Important – Please read these instructions fully before starting assembly

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

Cam Lock Assembly Instructions

	Diagram A Insert Cam Bolt into hole as shown in diagram A.
	Diagram B Make sure not to insert the Cam Bolt: Too deep as shown in figure B as this will cause the Cam Lock to be misaligned and unable to interlock properly.
	Diagram C Also avoid inserting the Cam Bolt too close to the surface of the hole as shown in figure C, as this will cause the Cam Lock to be too loose, and not interlock properly.
	Connect the panels together.
	ARROW SIGN Insert the Cam Lock so the side opening fits over the head of the Cam Bolt.
	To tighten the Cam Lock, turn it clockwise on half a turn with a flat screwdriver. <i>*Do not use an automatic screwdriver as it may bend or break if too much power is imposed.</i>



Ax24



Bx24



Cx 22




Dx 8




Ex 4



Fx 32




Gx 8



Hx 4



Ix 1



Jx16



Kx 24



Lx4



Mx 8



Nx 16




Ox 12




CRx2




CLx2





DRx2






DLx2





STEP 1






STEP 2







STEP 3




STEP 4






STEP 5





STEP 6




STEP 7




STEP 8





STEP 9





STEP 10




STEP 11



STEP 12




STEP 13




Mx8




Gx8



Ix1




STEP 14




Lx4




Cx10




Fx4




STEP 15



Ax8




Ex2



Hx2




STEP 16




Dx8




STEP 17



STEP 18



STEP 19



STEP 20

