











ASSEMBLY INSTRUCTIONS






				
Ø 6x35mm	Ø 15x12mm	Ø6x30mm	Ø 5x60	
AX6	BX6	CX12	DX6	EX1
	 Ø3x14mm			 Ø8x35mm
FX2	GX12	HX1	IX8	JX5
		 Ø4x16mm		 Ø4x25mm
KX4	LX4	MX48	NX4	OX8
	 x2    			
PX8	QX1			RX4


STEP 1




	
HX1	J X 1

STEP 2




		
Ø6x30mm	Ø 5x60	
CX6	DX6	EX1

STEP 3





	
	Ø8x35mm
HX1	JX4

STEP4




STEP 5




				
Ø 6x35mm	Ø6x30mm			Ø 3 x14mm
AX6	CX6	EX1	FX2	GX4


STEP 6



	
Ø 15x12mm	
BX6	EX1


STEP 7
x2



			
	Ø 4x16mm		Ø4x25mm
KX4	MX8	NX2	OX4




STEP 8

x2



LX4	Ø 4 x16mm	NX2	Ø4x25mm


STEP 9




NOTE: If the doors are uneven or there is a gap in the middle, loosen or tighten the screw on the door hinge until they are sitting flush.


Ø4x16mm	
MX32	RX4

STEP 10




STEP 11



	 Ø3x14mm		 x2 Q 1  Q 2  Q 3  Q 4  Q 5
EX1	GX8	PX8	QX1

STEP 12




Assembly Steps(EN) / Montageschritte(DE)

HOW TO ADJUST THE HINGES TO ALIGN THE DOORS IF NEEDED.


STEP 1

Open the door.




STEP 2

Adjust the door panels up or down



STEP 3

Adjust the flush between door panel and side panel



STEP 4

Adjust the Gap between door panel and side panel

